

Assembling Bulk Headers

1. First drill holes using 1/8 size drill bit.
2. Remove strip from double sided tape.
3. Line up and attach sign
4. Drill 3 adjacent holes and apply screws and wing nuts.
(Apply pressure/weight if needed to assure tape bonds)

